


The MICRO SCALE DECAL is the finest, most versatile decal made. It will conform to the irregular surfaces found on models because of its strength and flexibility. These characteristics are not found on any other decal made. When used with the MICRO SCALE SYSTEM, the MICRO SCALE DECAL will help produce the most realistic scale models.

The MICRO SCALE SYSTEM is simple to use but each step must be followed as described to assure perfect results. The instructions are contained in the following listing of the steps.

The MICRO SCALE DECAL SYSTEM

1. Surface to be decalated must have a smooth, glossy, painted finish. Do not apply decals to unpainted surfaces or they will not adhere. To obtain this surface either paint the model with MICROGLOSS over primer model or uneven patches will appear when the flat finish is added later. Allow paint to dry thoroughly.
2. For best results, surface to be decalated should be horizontal. A small vise is helpful here, or a box can be made into a jig to allow the model to lay on its side.
3. Cut each decal subject from the sheet only as needed. DO NOT cut clear film away from decal. Using tweezers, dip decal compoundly in water. Then remove and allow decal adheres to softening. Use a soft, medium-size brush, a No. 7 red sable water color brush is ideal, and wet the area to be decalated with a few drops of MICRO SET (blue label). This contains a wetting agent and helps eliminate tiny air bubbles.
5. Holding the decal paper with tweezers, use the brush to slide the loosened decal into the MICRO SET on the model.
6. Now place a few drops of MICRO SOL (red label) directly onto the decal and position the decal exactly where it is to remain.
7. The MICRO SOL will take the decal into contact exactly to the surface. This process is called "THE MICRO SOL WILL WRINKLE AND DISTORT DO NOT TOUCH IT!" THIS IS NATURAL AND AN IMPORTANT PART OF THE SYSTEM! As the decal dries it will flatten out and lay down. Do not touch the decal until it is completely dry. The decal will be held to the surface by the paint beneath. Actual drying time will vary according to temperature and humidity.
8. When decal is dry, examine it for any air bubbles. If any are found, puncture them with a sharp needle and put a drop of MICRO SOL over the bubble and allow to dry.
9. Carefully examine the clear film to be sure no flaking has appeared. If any is present, puncture the flaking with a sharp needle and apply MICRO SOL from the entire model.
10. After the decal has dried for several hours, carefully wash the decal adhesive from the entire model.
11. After the decal has dried for at least 12 hours, complete the model by spraying with either MICRO FLAT or MICRO GLOSS, depending on the sheen desired on the finished model.



33303

SPECIAL SPRG D-5
C136 WHEELS
S-65-2 HAND BRAKE
WARCOBPC 8/22CYL
WEST M.R.-500 DRAFT GEAR
WITH AAR YACHT FOLLOWER

PHOTO COURTESY DON GOLDE
CAR IS AVAILABLE FROM MODEL DIECASTING.

Additional super detailing decals are available on Micro Scale sheets 87-1, 87-2 & 87-193.

THE FOLLOWING PUBLICATIONS WILL PROVIDE ADDITIONAL INFORMATION:

- RAILROAD MODEL CRAFTSMAN
- PROTOTYPE MODELER
- RAILROAD MODELER
- PACIFIC NEWS
- EXTRA 2200 SOUTH
- MODEL RAILROADER
- TRAINS
- RAILPLAN
- RAIL CLASSICS
- CARSTENS PUBLICATION BOOKS
- KALMBACH PUBLISHING CO. BOOKS

